
CL250 Coastal Cargo Lift

Transports up to 250 lbs. indoors or out — corrosion-resistant finish is ideal for coastal areas.


- Pre-installed car and drive system on track section for fast, easy installation.
- No pulleys to install
- Wired call/send controls (constant pressure)
- AC-powered belt-driven winding cable / 90 VDC ½ hp motor
- 15 VDC control circuit
- Car: 36" x 24" (91.4 cm x 61 cm) with 24" (61 cm) high panels
- Slack cable brake; electrical shut off
- Upper and lower landing limits, upper final limit

CL350 Incline Cargo Lift

Mounts easily on stairway to move up to 350 lbs. Folds when not in use to increase space for foot traffic.



 Operates on standard 115 VAC household current



- Mounts to staircase, not wall
- Intended to carry cargo only
- Constant pressure controls



CL350 OD Outdoor Incline Cargo Lift

As above with:

- Zinc-plated components
- Multiple covers designed for exterior environments

General Specifications	CL250	CL350
Rated Load:	250 lbs. (113 kg)	350 lbs. (160 kg)
Drive:	AC Powered, belt driven winding cable / 90 VDC ½ hp motor	AC Powered, belt driven winding cable / 90 VDC 1/3 hp motor
Power Supply:	115 VAC 20 amp grounded circuit	115 VAC 20 amp grounded circuit
Control Circuit:	15 VDC	24 VAC
Platform / Car:	36" x 24" (91.4 cm x 61 cm) with 24" (61 cm) high panels	18" x 36" (46 cm x 91.4 cm)
Folded Width:	N/A	14" folded
Travel:	10' 6" (320 cm) standard; available up to 26' (7.9 m)	Up to 25' (Weight limit reduced to 250 lbs. if over 19')
Speed:	20 feet per minute	20 feet per minute
Controls:	Wired call / send controls (constant pressure)	Wall mounted call / send controls (constant pressure)
Safety Features:	Slack cable brake with electrical shut off	Platform folds to save space when not in use
	Upper and lower landing limits	Slack Cable Brake with electric shutoff
	Upper final limit	Upper and lower landing limits, Upper final limit
Warranty:	1-year on parts	1-year on parts





