

Indoor/Outdoor Enclosed System for Up to 14' Rise

The Highlander Enclosed CPL is an easy, cost-effective solution for indoor or outdoor installations. Factory-enclosed walls, integrated doors and gates, choice of drive options and platform sizes, plus an extensive accessory portfolio fit a wide range of applications.

Features & Benefits


- Non-skid 36"x60" straight-through platform; other sizes available.
- Rated load: 750 lbs.

Optional

- Three-stop capable
- Fixed ramp
- Power door operators
- Acrylic panels for door
- Exterior acrylic dome roof, extending 6'8" above the upper landing
- Power ventilation system
- In-frame call station
- Straight-thru and 90-degree configurations
- Custom colors and Coastal Finish available



Specifications	EPL400
Lifting Height:	EPL400 53" EPL600 77" EPL800 101" EPL1000 125" EPL1200 149" EPL1400 171"
Rated Load:	750 lbs.
Drive:	Belt driven ball screw/90 VDC 1/3 hp motor with brake. Optional: 24 VDC battery powered unit. Optional: 2.1 roped hydraulic drive
Power	120 VAC 15A 240 VAC optional
Control Circuit:	24 VAC (Low Voltage Controls)
Standard Platform:	36" x 60" with 42" high guard panels and grab rail, stationary ramp / 42" x 60" with 42" high guard panels
Footprint:	54" x 65" / 60" x 65"
Speed:	10 fpm
Controls:	Constant pressure paddle switch w/ emergency stop (key switch optional)
Manual Lowering:	Standard
Safety Design:	ASME A18.1, Section 2 - Vertical Platform Lifts
Standards:	CSA B44.1/ASME A17.5 - Elevator & Escalator Equipment
Safety Features:	Safety pan, (optional on EPL) final limit, ball nut safety backup, belt monitor and non-skid surface
Warranty:	2-year parts (1-year on outdoor units)



Oyster white (standard) or custom RAL color options ensure an attractive blend with building aesthetics.

Engineering Support

For more information, see www.harman.com for specifications, visit www.arcat.com, or call for a free copy of Harman's Highlander VPL Planning Guide.

