

Foam Tipped Applicator

Polypropylene shaft



Actual Size

Description

This foam tipped applicator is produced with reticulated 100ppi foam. It is thermally bonded to a rigid glass filled polypropylene shaft. Pointed tip is excellent for cleaning crevices and hard to reach areas.

Dimensions

3.26" Overall Length (82.804 mm)

Tip

- 0.688" Length (17.475 mm)
- 0.156" Dia. (3.962 mm)

Handle

- 3.210" Length (81.534 mm)
- 0.1" Dia. (2.54 mm)

Standards

- ISO 9001:2008
- FDA GMP's

Qualities

- Lint and residue free
- Soft and non-abrasive
- Can be used with IPA and DI water, or dry

Applications

Critical Environment / Industrial

- Cleaning electronics and equipment
- Removing contaminants and residues
- Applying solutions
- General cleaning

Ref #	Packaging
1623-PF	20/50 (20 resealable poly bags per case, 50 swabs per bag)

Actual Size



Specialty Applicators

Puritan Medical Products Company LLC
Guilford, Maine 04443-0149 USA

Tel 800-321-2313 (US and Canada Only)
207-876-3311

Fax 800-323-4153
207-876-3130

Web www.puritanmedproducts.com

Email sales@puritanmedproducts.com

1-800-321-2313
puritanmedproducts.com

Foam Tipped Applicator

Polypropylene Shaft

1623-PF

NVR

NON-VOLATILE RESIDUE

Test method IDEMA method M7-98

NVR Solvent - Hexane

NVR 32 µg/swab

The minimum detection limit for NVR is 10 µg/swab

ION CHROMATOGRAPHY TESTING RESULTS

IONIC CLEANLINESS

Test method IDEMA M13-99 (anions) M12-99 (cations)

ANIONS

Fluoride	ND	µg/swab
Chloride	1.0200	µg/swab
Nitrate	ND	µg/swab
Bromide	ND	µg/swab
Nitrate	ND	µg/swab
Sulfate	ND	µg/swab
Phosphate	ND	µg/swab

CATIONS

Lithium	ND	µg/swab
Sodium	0.2240	µg/swab
Ammonium	ND	µg/swab
Potassium	0.0520	µg/swab
Magnesium	ND	µg/swab
Calcium	<0.0268	µg/swab

ND - Non Detected

Test procedures available upon request.



Specialty Applicators

Puritan Medical Products Company LLC
Guilford, Maine 04443-0149 USATel 800-321-2313 (US and Canada Only)
207-876-3311Fax 800-323-4153
207-876-3130Web www.puritanmedproducts.comEmail sales@puritanmedproducts.com1-800-321-2313
puritanmedproducts.com